

OPTi® Beer & Wine

PORTABLE REFRACTOMETERS FOR QUALITY CONTROL + MEASUREMENTS ON-THE-GO

The pocket-sized refractometer for beer & wine

OPTi digital handheld refractometers are ideal for beer & wine applications thanks to their durable, IP65 pocket-sized design, quick 2 second read time and broad selection of scales. From home-brew beer to the microbrewery and beyond, our refractometers have been helping brewers for years. In the beer world, refractometers are used to measure Wort prior to fermentation as well determining alcohol content. We supply OPTi refractometers to vineyards around the globe so that grape ripeness can be checked before harvest, sugar content assessed and alcohol content measured in the final stages of production.

OPTi® Digital Handheld Refractometers

- Quick 2 second read time.
- Onboard library of over 40 scales.
- 3 active scales on a single device.
- High Ambient Light (HAL) detection warns of too much light entering the sensor.
- Clear digital LCD display.
- Unique "AG Test Mode" that allows the use of long-life non sucrose based certified reference materials.
- Durable IP65 pocket sized design.
- Programmable read delay for sample temperature stabilisation.



a xylem brand

OPTi Refractometers FOR THE BEER & WINE INDUSTRY

OPT-BW-EN120

Application	Scale	Units	Range	Resolution	Accuracy	ATC*
Primary	°Brix (ATC)		0-95	0.1	±0.2	°Brix
Primary	°Brix		0-95	0.1	±0.2	None
Wine & Beer	°Baumé		0-50	0.1	±0.2	°Brix
Wine & Beer	°Zeiss (ABV)	% Volume / Volume	10-135	0.1	±0.5	°Brix
Wine & Beer	Alcohol Probable (AP)		0-22	0.1	±0.2	°Brix
Wine & Beer	KMW (Babo)		0-25	1	±1	°Brix
Wine & Beer	Oechsle (German)		30-130	1	±1	°Brix
Wine & Beer	Oechsle (Swiss)		0-130	1	±1	°Brix
Wine & Beer	°Plato		0-30	0.1	±0.2	°Brix
Wine & Beer	Mass Sugar (°Brix) (ATC)	% Weight / Weight	0-95	0.1	±0.2	°Brix
Wine & Beer	Mass Sugar (°Brix)	% Weight / Weight	0-95	0.1	±0.2	None
Wine & Beer	Wort (Sucrose Equivalent)	Specific Gravity (d20/20)	1.000-1.120	0.0005	±0.001	°Brix

Additional Scales ONBOARD SCALES ALL AVAILABLE WITHIN THE SAME DEVICE



Application	Scale	Units	Range	Resolution	Accuracy	ATC
Primary	Refractive Index (ATC)		1.33-1.53	0.0001	±0.0003	°Brix
Primary	Refractive Index		1.33-1.53	0.0001	±0.0003	None
Automotive	AdBlue®/DEF (NOx reduction)	% Weight / Weight	0-40	0.1	±0.2	AUS32
Automotive	Ethylene Glycol	°C Freezing Point	0 to -50	1	±1	EG
Automotive	Ethylene Glycol	°F Freezing Point	30 to -40	1	±1	EG
Automotive	Propylene Glycol	°C Freezing Point	0 to -50	1	±1	PG
Automotive	Propylene Glycol	°F Freezing Point	30 to -40	1	±1	PG
Food & Beverage	°Butyro		0-100	0.1	±0.5	Butyro
Food & Beverage	42 HFCS (High Fructose Corn Syrup)	% Weight / Weight	0-95	0.1	±0.2	°Brix
Food & Beverage	55 HFCS (High Fructose Corn Syrup)	% Weight / Weight	0-95	0.1	±0.2	°Brix
Food & Beverage	90 HFCS (High Fructose Corn Syrup)	% Weight / Weight	0-95	0.1	±0.2	°Brix
Food & Beverage	Fructose	% Weight / Weight	0-85	0.1	±0.2	°Brix
Food & Beverage	Glucose	% Weight / Weight	0-85	0.1	±0.2	°Brix
Food & Beverage	Invert Sugar	% Weight / Weight	0-85	0.1	±0.2	°Brix
Food & Beverage	Maltose	% Weight / Weight	0-60	0.1	±0.2	°Brix
Food & Beverage	Salinity (NaCl)	% Weight / Volume	0-28	0.1	±0.2	NaCl
Food & Beverage	Total Solids of Waste Milk	%	5-15	0.1	±0.5	°Brix
Food & Beverage	Water in Honey	%	10-30	0.1	±0.2	Honey
Industrial	Arbitrary		0-95	0.1	±0.2	
Industrial	Calcium Chloride	% Weight / Weight	0-40	0.1	±0.2	CaCl2
Industrial	Ethanol	% Volume / Volume	0-20	0.5	±1	Ethanol
Industrial	Ethylene Glycol	% Volume / Volume	0-60	0.1	±0.4	EG
Industrial	Ethylene Glycol	% Weight / Weight	0-60	0.1	±0.4	EG
Industrial	FSII DiEGME (ASTM D 5006)	% Volume / Volume	0.0-0.25	0.01	±0.02	°Brix
Industrial	Hydrogen Peroxide	% Weight / Weight	0-50	0.2	±0.5	°Brix
Industrial	Methanol	% Weight / Weight	0-40	1	±0.2	Meth
Industrial	Propylene Glycol	% Volume / Volume	0-60	0.1	±0.4	PG
Industrial	Sodium Sulphate	% Weight / Weight	0-22	0.1	±0.2	Na2SO4
Industrial	Starch	%	0-30	0.1	±0.2	°Brix
Industrial	Sulphuric Acid (Battery Acid)	Specific Gravity (d20/20)	1.000-1.501	0.001	±0.003	SA
Industrial	Urea (CRC data)	% Weight / Weight	0-40	0.1	±0.2	AUS32
Life Science	Colostrum Quality		Poor / PASS	Poor / PASS	±0.2	°Brix
Life Science	Seawater (Practical Salt Units)	Part Per Thousand	0-180	1	±1	NaCl
Life Science	Seawater (Practical Salt Units)	Specific Gravity (d20/20)	1.000-1.090	0.0005	±0.001	NaCl
Life Science	Serum Protein	g/100ml	0-30	0.1	±0.2	°Brix
Life Science	Urine (SG) Human	Specific Gravity (d20/20)	1.000-1.050	0.0005	±0.0010	°Brix
Life Science	Urine (SG) Large Mammal	Specific Gravity (d20/20)	1.000-1.050	0.0001	±0.0010	°Brix
Life Science	Urine (SG) Small Mammal	Specific Gravity (d20/20)	1.000-1.050	0.0005	±0.0010	°Brix

*Automatic Temperature Compensation

www.bellinghamandstanley.com



Bellingham + Stanley
 Xylem
 Longfield Road
 Tunbridge Wells
 Kent, TN2 3EY
 United Kingdom
 Tel: +44 (0) 1892 500400
 Email: sales.bs.uk@xyleminc.com

Bellingham + Stanley (USA)
 Xylem
 151 Graham Road
 College Station
 TX 77845
 USA
 Tel: +1 (979) 690-1711
 Email: sales.bs.us@xyleminc.com